



# iMac G5 20" Model A1145 Front Bezel Replacement

Written By: Andrew Bookholt



## INTRODUCTION

Remove the front bezel to access your iMac's internals.

---



### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
  - [Plastic Cards](#) (1)
  - [T8 Torx Screwdriver](#) (1)
-

## Step 1 — Access Door



- Orient the iMac face-side down on a table with the bottom edge facing yourself.
- Remove the two Phillips screws securing the access door to the bottom grille of your iMac.
- ⓘ The screws are captive in the access door.

**⚠ Before beginning the repair, unplug the computer and press and hold the power switch for 20-30 seconds, to discharge internal capacitors.**

## Step 2



- Remove the access door.





## Step 3 — Front Bezel



- Remove the three T8 Torx screws securing the front bezel to the rear case along the lower edge of the iMac.

## Step 4



- Turn the computer over.
- Use your thumbs to press both RAM arms in past the front bezel for enough clearance to lift it off the rear case.

## Step 5



- While holding the RAM arms in with your thumbs, lift the lower edge of the front bezel enough to clear the rear case.

## Step 6



- ⓘ Re-orient your iMac so it sits upright on the stand.
  - Insert a plastic card up into the corner of the air vent slot near the top of the rear case.
  - Push the card toward the top of the iMac to release the front bezel latch.
  - Pull the front bezel away from the rear case.
  - Repeat this process for the other side of the front bezel.
- ⓘ It may be necessary to apply several layers of duct tape to the top of the access card to aid in releasing the latches.
  - If the bezel refuses to release, try pressing the lower edge back onto the rear case and repeat this opening process.
- ⓘ Alternatively, you can use a strong magnet by holding it to the front top left/right corner of the display. You will hear a snapping sound when the hatch is released.




## Step 7




- Lay your iMac stand-side down on a table.
- Lift the front bezel from its lower edge and rotate it away from the rest of your iMac, minding the RAM arms that may get caught.
- Lay the front bezel above the rest of the iMac.

## Step 8



- If necessary, remove the piece of kapton tape wrapped around the microphone and camera connectors.

## Step 9



- Disconnect both the camera and microphone cables.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 02:40:42 AM.